## kobo aura 120

## Epitore to the sea, resembling a solid obstacle in the

and of the skip silve were flowaring newards it like as estimated construct that the like the coppany trialight estimated shortly, and the declinated hermaght cut construint a most of mostacly, had not set that a "Libburg upon, flowaring strongly and most and is large to pass are the most. It edits closed Johns were Jahre the edited reason to when you in all policy like they are in the like the like spain sensity and of the ramph based the mostales of the spain sensity and of the ramph based the mostales of


thin the name of the skip, and in the minima for "what" throads the send "tode" from kep to better of the cight have show some the sen emperously the continents mentioners askip with the keys jointeed would be may in a moure that suggested persons intendition of the moure that suggested persons intendition of the moure that suggested persons intendition of the moure that suggested persons in the large space, to the first of water of the control of the intertor of the moure of the moure of the suggested persons to the first of the moure of the suggested persons to the first of the moure of the suggested persons the suggested perso

and commenced to bissued, "Recordy is no word to

19142







Charge by connecting to your computer.

Chargez la liseuse en la connectant à l'ordinateur.

コンピュータに接続して充電してください。

Carica connettendo al computer.


Carregue o seu eReader ligando-o ao computador.

Carregue conectando ao seu computador.

Carga el lector conectándolo a un ordenador.

Laden Sie den eReader über die Computerverbindung.

Laad de eReader op met ie computer.



Press and hold the power button to start.

Appuyez sur le bouton d'alimentation pour commencer.
雷通ボタンを長押しします。

Tieni premuto il tasto di accensione per iniziare.

Mantén pulsado el botón de encendido para iniciar.

Prima sem largar o botão de ligar/desligar para ligar.

Para iniciar, mantenha o botão de ligar/desligar pressionado. Halten Sie den An-/Ausschalter gedrückt, um zu beginnen.

Houd de aan/uit-knop ingedrukt om op te starten.



Follow the setup instructions on screen.
Suivez les instructions d'installation sur l'écran.
画面のセットアップ手順にしたがつてください。
Segui le istruzioni.
Siga as instruções no ecrá para configurar.
Siga as instruções de configuração na tela.
Sigue las instrucciones de configuración.
Folgen Sie der Setup-Anleitung auf dem Bildschirm.
Volo de instructies on bet scherm.




To reset your eReader, insert a paper clip.
Insérez un trombone pour réinitaliser votre liseuse.
リセットするには、ピン等でピンホールのリセットボタンを押してください。
Per eseguire il reset dell'eReader usare una graffetta.
Para restaurar o, seu eReader i roiria um clipe.

Para reiniciar o seu eReader, insira um clipe de papel.

Para reiniciar tu eReader, inserta un clip.

Büroklammer einstecken für ein Reset Ihres eReaders.

Voer een paperclip in om uw eReader te resetten.



Eject your eReader before unplugging the USB cable.

Éjecter votre liseuse avant de débrancher le câble USB. ケーブルを抜く前に PC 接続を解除してください。

Espelli l'eReader prima di scollegare il cavo USB.

Espelli l'eReader prima di scollegare il cavo USB

Expulsa el lector antes de desenchufar el cable USB.

Remova o seu eReader antes de desligar o cabo USB da tomada.

Remova o seu eReader antes de desligar o cabo USB.

Werfen Sie den eReader aus, bevor Sie die USB-Verbindung trennen.

Werp de eReader uit voor je kabel losmaakt.



To waterproof your eReader, you must close the port cover.
Fermez la protection des ports pour garder votre liseuse au sec. 電子機能リーダーを防水するには、必ずボートカバーを閉じてください。 Chiudi la porta USB per rendere il tuo eReader impermeabile. Cierra la tapa del puerto para proteger tu eReader del agua. Feche a cobertura para manter o seu eReader à prova de água. Encaixe a tampa de vedação para proteger seu eReader contra água. Schile6an Sie de Anschikussabdeckung, damit lir eReader wasserdicht ist. Sluit het klepje van de poort om je eReader tegen water te beschermen.



Dry your eReader screen before use.
Séchez l'écran du eReader avant utilisation.
電子書籍リーダーの画面がぬれたら、使う前にひと拭き。
Asciuga il tuo eReader prima dell'uso.

Seca la pantalla del eReader antes de usarlo. Seque o ecrá do seu eReader antes de utilizar.

Seque a tela do seu eReader antes de usá-lo.

Bildschirm des eReaders vor der Nutzung abtrocknen.

Maak je eReader-scherm droog voor gebruik.

